

Integrated dispensing tip alignment ensures consistent dispensing placements

In an automatic dispensing application, the tooling for both the target workpiece and the dispensing needle are critical to positional accuracy. Even with the best set up, the dispensing needle or nozzle can move relative to the original position from which the programming was generated. This can readily occur if dispensing direct from a syringe barrel or cartridge, which will need to be replaced with a full one when empty. A similar shift can happen when the dispensing needle itself is replaced. Occasionally, dispensing needles may get slightly bent during handling, cleaning or machine set-up. These displacements may not be very large, but it can be in any x, y and/or z axis, and might be enough to influence the quality of your material application.

To address these variations, we offer two [Dispensing Tip Alignment Kits](#) for Fisnar dispensing robots – a mechanical version, and an automatic one. By using a dispensing tip alignment module, you can achieve fast and reliable tip alignment, meaning less downtime between material or needle changes.

The **FISTA360U-KIT Mechanical Tip Alignment Kit** allows the dispensing hardware mounted on the robot to be mechanically adjusted in the x, y & z axes using adjustment screws. The dispense tip is quickly and easily adjusted by re-aligning it to a known location which is set in the robot program. Re-alignment can be carried out independently to the program and adjustments can be easily made by users not trained in robot programming, as integrated into operator instructions. The **FISTA360U-KIT Mechanical Tip Alignment Kit** is suitable for all Fisnar robots.

Integrated dispensing tip alignment ensures consistent dispensing placements



The Fisnar TA360U-KIT Tip Alignment Kit

When the **FIS4000AKIT Tip Alignment Module** is installed, it runs as a function on the robot that detects the dispensing tip centre point and then automatically offsets the program in all axes based on the new dispense tip position. It is suitable for when a higher level of assurance is required, or when material and needle changes are frequent.

Integrated dispensing tip alignment ensures consistent dispensing placements

Dispensing tip alignment modules improve dispensing precision, resulting in fewer rejects, less downtime, and better productivity.

Supplied by:

intertronics

INTERTRONICS

12a Station Field Industrial Estate, Banbury Road, Kidlington

Oxfordshire England OX5 1JD

t 01865 842842 e info@intertronics.co.uk

Last updated: March 2020

Statements, technical information and recommendations contained herein are based on tests we believe to be reliable but they are not to be construed in any manner as warranties expressed or implied. The user shall determine the suitability of the product for his intended use and the user assumes all risk and liability whatsoever in connection therewith.