

# Catheter adhesive - how do you know it's cured?

## Description

[Dymax 214-CTH-UR-SC adhesive](#) has been formulated to incorporate both [Ultra-Red](#) and [See-Cure](#) technologies. Designed to be used in catheter assembly and other medical device assembly applications, it offers excellent bond strength to a number of plastics including PEBA and Nylon 12.

[Dymax 214-CTH-UR-SC](#) is blue in colour when in its uncured state, enabling easy verification of correct application. When exposed to sufficient levels of UV curing light the adhesive becomes clear to provide visual confirmation that the adhesive is fully cured. Also incorporated is *Dymax Ultra-Red fluorescing technology* – the adhesive fluoresces a bright red colour under black light. This allows manufacturers to easily incorporate automated or manual quality inspection ensuring accurate and complete placement of the cured adhesive.

Optimal curing of 214-CTH-UR-SC is achieved when cured with a [Dymax LED light-curing system](#). LED light curing systems provide users with a number of significant advantages over more conventional lamp curing. These include cooler curing temperatures, lower energy consumption, more consistency in cure results, lower intensity degradation over time and reduced costs.

# Catheter adhesive - how do you know it's cured?



Supplied by:

**intertronics**

INTERTRONICS

12a Station Field Industrial Estate, Banbury Road, Kidlington

Oxfordshire England OX5 1JD

t 01865 842842 e [info@intertronics.co.uk](mailto:info@intertronics.co.uk)

Last updated: October 2019 Version:

Statements, technical information and recommendations contained herein are based on tests we believe to be reliable but they are not to be construed in any manner as warranties expressed or implied. The user shall determine the suitability of the product for his intended use and the user assumes all risk and liability whatsoever in connection therewith.