

# Thinky Mixer provides rapid, one step dispersal and degassing

The **Thinky ARE-500 mixer** is the latest addition to our range of high performance industrial non-contact “planetary” mixers; suitable for all engineering compounds – liquids, pastes and powders. It mixes, disperses and degasses materials in seconds to minutes, in a sealed or lid-less container such as a jar, beaker, syringe tube or cartridge using a non-contact mixing principle which makes it possible to formulate compounds from very small amounts such as 0.5ml to large production scales up to a full 1.1kg, while mixing and removing bubbles simultaneously. The **Thinky ARE-500 conditioning mixer** can be used for the mixing and/or bubble removal of epoxies, silicones, conductive pastes, medicines, laboratory or production chemicals, and many other fragile or complex materials. Typical mixing times are in the order of a few seconds to a few minutes, depending on material viscosities and complexities – a viscous epoxy resin and hardener can be homogeneously mixed with aluminium powder filler in a few minutes, for example.

The **Thinky ARE-500** stores five different sets of mixing and degassing conditions (time and speed per mode) in a single batch cycle which consolidates otherwise time consuming formulation into a single step, completing in seconds to minutes what might otherwise take a great deal longer. Precise control of the mixing/dispersion process makes it possible not only to deliver improved and consistent formulation quality, but also to eliminate human errors and the need to rely on special operator skills. Shear forces are minimal so as not to damage delicate materials, whilst cooled or heated materials can be processed using special adapters. Standard containers range from 650ml jars right down to small syringes. The ability to mix in your own container eliminates the need to clean between batches, saving significant time and lowering costs, while improving yield rate.

**Thinky mixing and degassing** has been found valuable for high viscosities, for materials with highly different densities, or for mixing dry particles into liquids. The simultaneous process of dispersion and degassing in one batch gives major time savings. It can remove voids and re-disperse filled materials

# Thinky Mixer provides rapid, one step dispersal and degassing

in pre-packed syringes prior to use. The non-invasive processing eliminates any risk of cross contamination between batches. The ability to process quantities as small as 0.5ml saves wastage of valuable materials, while re-mixing of separated materials can prolong shelf life and save stock costs.

The **Thinky ARE-500** has a high-durability drive system suitable for production and enabling up to 500ml or 1.1kg of material to be simultaneously mixed and de-aerated. Material possibilities include adhesives, sealants, moulding compounds, lubricants, slurries, coatings, inks, paints, abrasives, bio chemicals, cements, medical compounds, cosmetics/personal care materials, detergents, conductive pastes, dental materials, foods, construction materials or any other materials which are hard-to-mix or hard-to-degas.

Come and see one in action in our *Technology Centre* or learn more with our [introduction to Thinky Mixers](#).

# Thinky Mixer provides rapid, one step dispersal and de-gassing



Supplied by:

**intertronics**

INTERTRONICS

12a Station Field Industrial Estate, Banbury Road, Kidlington  
Oxfordshire England OX5 1JD

t 01865 842842 e [info@intertronics.co.uk](mailto:info@intertronics.co.uk)

# **Thinky Mixer provides rapid, one step dispersal and degassing**

Last updated: April 2018

Statements, technical information and recommendations contained herein are based on tests we believe to be reliable but they are not to be construed in any manner as warranties expressed or implied. The user shall determine the suitability of the product for his intended use and the user assumes all risk and liability whatsoever in connection therewith.